

04 - Calibration via Diagnostic Tool and Built-In Screen

Using the Diagnostic Tool and Built-In Screen to calibrate the GSS-LABEL-PTR-I industrial printer.

Written By: Ian Savitch

Discrimination of the second sec	
4	
Open	
Run as administrator	
Share with Skype	
Troubleshoot compatibility	
Unpin from Start	
Pin to Start menu (Classic Shell)	
Scan with Windows Defender	
🖻 Share	
Give access to >	
Pin to taskbar	
Burn with Nero	
Restore previous versions	
Send to /	
Cut	
Сору	
Create shortcut	
Delete	
Rename	
Properties	
Properues	

INTRODUCTION

Before starting, ensure that the power is connected to the printer and that the printer is connected to the PC via a USB cable. This will ONLY work if the labels for the printer are already loaded. If they are not, please see the previous guides for the Global Shop industrial label printer.

Step 1 — Calibrating via USB - Pt.1

	DiagTool V1.64 Unit Unit Unit Or inch C mm Unit Unit
Open Image: Provide State Stat	Printer Function Printer Endigeration Calitade Sensor Printer Information Ethernet Setup Printer Information RTC Setup Deck Sum: Control Deck Sum: Control Deck Sum: Control Deck Sum: Common Z D Printer Function Speed Factory Default Speed Printer Test Page Pager Height Print Test Page Pager Height Configuration Page Media Sensor Dump Text Gap Ignore AUTO BAS Positified Control Ignore AUTO BAS Positified Control Pager Height 602 Configuration Gap Dump Text Gap Olizet Ignore AUTO BAS Positified Control Positified Cont TEA Password Setup Direction Direction O Direction O Direction O Get Statur Deal Direction O Direction O Direction

- Launch the Diagnostic Tool (DiagTool) software.
 - <u>https://www.emsbarcode.com/gss/GSS-LABEL...</u>
- The fields should populate, and the "Version" box should read "MA240T ..."
- If the fields do not populate, make sure the printer is turned on and the USB connection between the printer and the computer is good.

Step 2 — Calibrating via USB - Pt.2

Language English	Unit Grinch C mm	Intelace English Grinch C mm US8 Setup
Printer Configuration File M Printer Function Calitizate Sensor Ethernet Setup RTC Setup Factory Default Reset Printer Print Test Page Configuration Page Dump Text Ignore AUTO.BAS Exit Line Mode Password Setup Active Emulation	Janger Binnep Ford Manager Command Tod Privet criffication Privet criffication Senial No. 2411 9270025 Meager: 0.0031 Dreck: Sum: 0C443095 Common JZ D Deck: Sum: 0C443095 Common JZ D Bager Hight 6.02 Den: Variation N Paper Width 4.05 Speed 4 Regree Hight 6.02 Gap Olize inch Reference Gap Inter. Gap Olize inch Reference 0 Brief Inter. 9 Density 5 Reference 0 Bay Olitet 0000 Direch Gap Inter. Bay Olitet 0 Densitiver. 2 Officet 0 Bay Olitet 0 Bay Internence 0 Bay Internence 0 Bay Internence 0	Printer Enclaion File Manage Elimana Fork Manage Command Tod Printer Finderson Calibrate Sensor Finder Finderson Ethernet Setup Factory Defaul Reset Printer Print Test Page During Test Lignore AUTO Be Calibrate Sensor Factory Defaul Reset Printer Print Test Page Configuration Page Each Therehold Value Calibrate Sensor Configuration Page Calibrate Sensor Factory Defaul Reset Printer Bage Configuration Page Calibrate Sensor Configuration Page Calibrate Sensor Calibrate
Get Status	Clear Load Save Set Get	Get Status Clear Load Save Set Get

- Hit the "Calibrate Sensor" option at the top left of the window.
- In this new window, select the "GAP" option by clicking it's bubble, and then hit "Calibrate."
- In this process it will print a few blank labels. Please go to Step 6 to make sure the printer has calibrated correctly.

Step 3 — Calibrating via Ethernet - Pt.1

Language English	Unit Finch Cmm	Interface USB Setup	S TCP/IP Setup	lean land	— — X
Printer Configuration File M. Printer Function Calibrate Sensor Ethernet Setup RTC Setup Factory Default Reset Printer Print Test Page Dump Test Ignore AUTO.BAS Exit Line Mode Password Setup Active Emulation Printer Status	neger Bitmap Fort Manager Command Tool Private (Configuration Private (Configuration Version: M4240T Version: A2 11 EZD TCF Cutting Loc Setal No: [0C443095 Common Z D R5-232] Wreless Bluetooth Speed 4 Robon Density 5 Robon Encode Paper Height 6:03 inch Code Page Media Sensor GaP 0112 inch Head-up Senso Gag 011et 000 inch Repiret Alter En Pout-Print Action TEAR Maismun Leggi Cut Plece Gag Federate 0 0 Bite Infan. Direction 0 Continuous Inte Offet 0 Shitt V 0	USB (JP)	Discover Device Change IF Configuration Page Me Dump Test Ga Ignore AUTO BAS Po Exit Line Mode Co	10.121.90.61 M4240T Ready PAddress Factory Default Web Setup rda Sensor GAP Country Code up Offset 0.00 inch Reprint After f eterrore 0 0 Reine Inter	IP Address /Pinter Name 10.121.80.81 Port 9100 Exit corr ON Error 0N 10.000 inch 8
Get Status	Clear Load Save	Set Get	Active Emulation Dir	rection 0 Continuous In fiset 0 Threshold Del	iten. 2 tection AUTO 💌

- This method requires the printer to have been set up on the network with an IP. This is demonstrated in the guide "5 - Assigning an IP."
- Make sure the computer and printer are both turned on and connected to the network.
- Launch the DiagTool software.
- Click on "USB" at the top left to open the Interface drop down, and then select "Ethernet".
- Select the printer with the correct name and IP address (the printer displays it's IP address on it's screen, if you need to check), and then select "Exit".
 - ▲ It's important that you select the "Exit" button this is how you tell the program to load this printer. If you only close the window, it will still have the default printer loaded.

Step 4 — Calibrating via Ethernet - Pt.2

Language Frontish	Unit C mm	Interface ETHEBNET	▼ Setun	Language English	•	Unit (● inch ⊂ mm		ETHERNET -	Setup
Printer Configuration File Mas Printer Function Calibrate Sensor Ethemet Setup RTC Setup Factory Default Reset Printer Print Test Page Configuration Page Dump Test Ignore AUTO BAS Exit Line Mode Password Setup Active Emulation Printer Status	anger Bitmap Fort Manager Command Tool Private Configuration	Cutting Counter: 0 Mileage: 0.00 etooth 0 Ribbon Sensor 1 Seg Intern 1 Birle Intern 1 Continuous Intern 1 Treshold Detection 1	0 54 0.0054 Km 0FF × 0N × 0N × 001 × 0N × 001 × 0N × 01 × 0N × 400 × 001 × 000 ×	Printer Cont Printer Fu Cabb Ethe R Fact Print Config Du Ignote Exit Pass Activ	puration File Managaration Atte Servor ate Servor ate Servor C Setup C	ger Bitmap Fort Manager Com Private Information Private Information Version: M42401 Versio Senial No. Check Sunx Check Sunx Manual Bithrate Sensor Manual to Calibration Manual pin Inch Senial Calibrate 0 Direction 0 Direction 0 Officient 0 Direction 0 Shirt X 0 Shirt Y 0	And Tool x A2.11 E2D TCF [24119270026] [24119270026] [2413995] [240430000] [2404300000] [2404300	unter: 0 0 0 0.0054 0.00 Marks Ymm CapP Continuous Cancel Cancel	54 Km
Giet Status	Clear Load Save		Set Get	G	t Status	Clear Load	Save	Set	Get

- Hit the "Calibrate Sensor" option at the top left of the window.
- In this new window, select the "GAP" option by clicking it's bubble, and then hit "Calibrate."
- (i) The printer should now start calibrating in this process it will print a few blank labels. Please go to Step 6 to make sure the printer has calibrated correctly.

Step 5 — Calibrating via the Printer Screen



- Make sure the printer is connected to power and turned on.
- On the screen, press "Calibrate" with your finger, and then select "Gap".
- (i) The printer should now start calibrating in this process it will print a few blank labels. Please go to Step 6 to make sure the printer has calibrated correctly.

Step 6 — Checking the Calibration

♣ Diartool v1.64
Language Lindeface USB Setup
Printer Configuration File Manager Bitmap Fort Manager Command Tool Printer Function Printer Configuration Calibrate Sensor Printer Guidantian Ethernet Setup Printer Michael Off Version A2:11 E2D TOF Cutling Counter: 0 RTC Stabp Setel Michael OC43095 Maager: 0.0031 0.0031 Printer Function 2 D R5:232 Wreters: Bitbon Sensor 0 F Point Test Page Speed 4 Ribbon Sensor 0 F • Point Test Page Dump Test Speed 0 0 0 • 0 • Ignore AUTO BAS Pager Verlight 0.000 nich Regin Infen. 8 0 • Parter Field 0.00 nich Regin Infen. 8 0 •
Get Status Clear Load Save Set Get LPT1 [COM1 9600,N,8,1 RTS [11/5/2020 12:30:36 PM

- If the Calibration has worked correctly, you can know by checking the following:
 - The edge of the label paper is lined up with the edge of the printer, such that printed labels can easily be torn off.
 - In the Diagnostic Tool software, the correct label size is displayed (within a few thousandths of an inch is fine).
 - (i) For my setup, I'm using 4 inch wide by 6 inch long labels, which is what the software now displays.

Step 7 — If the Calibration Doesn't Work

English © rich rich <th>Unit Indeface US8 Setup ation File Maagaer [Disage Fort Maagaer Command Tool son Prieter Configuration Prieter Configuration Prieter Configuration Sensor Version: MA2401 Version: A211 EZD TCF Cutting Counter: 0 0</th>	Unit Indeface US8 Setup ation File Maagaer [Disage Fort Maagaer Command Tool son Prieter Configuration Prieter Configuration Prieter Configuration Sensor Version: MA2401 Version: A211 EZD TCF Cutting Counter: 0 0
Printe Configuration File Manager Bitmap Font Manager Command Tool Linguit Printel Function Printe Configuration Printe Configuration Printe Function Print	Sence Version
Printer Function Printer Configuation Printer Configuation Printer Configuation Calibrate Sensor Printer Function Printer Function Printer Function Printer Function Ethernet Setup Serial No. [24119270036] Malage: 0.052 0.052 Km Calibrate Sensor Ethernet Setup Ethernet Se	ation Fie Manager Bitmap Ford Manager Command Tool Son Privete Information Version: MA240T Version: A2.11 EZD TCF Cutting Counter: 0 0 0
Calibrate Sensor Version MA2407 Version: A211 EZD TCF Cuting Counter: 0 0 - - Printer Fundic Ethernet Solup Senis No: 3411 EZD TCF Cuting Counter: 0 0 Calibrate S Cal	Sensor Printer Lordigation Printer Information Version: MA2401 Version: A2.11 EZD TCF Cuting Counter: 0 0 0
Ethomet Setup Serial No. 241119270036 Mileage: 0.0052 0.0052 0.0052 Km RTC Setup Cmeck Sum: 0C4430 95 Ethomet Setup Ethomet Se	Sensor Version: MA240T Version: A2.11 EZD TCF Cutting Counter: 0 0
Exhibition of Gup Check Sum: IDC443095 Etheme 5 RTC Setup Common Z D R5:232 Variess Bluetooth RTC Setup RTC Setup	
RTC Setup Common Z D RS-232 Wieless Bluetooth RTC Se	Setup Serial No: 24113270026 Mileage: 0.0052 0.0052 Km
	Setup Check Sum: 0C443D95
Factory Default Speed 4 Bibbon DFF -	Common Z D RS-232 Wireless Bluetooth
Reset Printer Density 5 V Ribbon Sensor ON V	Default Speed 4 Ribbon OFF 💌
Paper Width 4.06 inch Ribbon Encoder Err. ON •	Printer Density 5 Ribbon Sensor DN
Prink i text Page Paper Height 6.03 inch Code Page 850 V	st Page Paper Width 4.06 inch Ribbon Encoder Err. ON 💌
Configuration Page Media Sensor GAP Country Code 001 Configuration	Paper Height 6.03 inch Code Page 850 V
Dump Text Gap 0.12 inch Headup Sensor ON 💌	Media Sensor GAP Country Code 001
Ignore AUTO BAS Gap Offset 0.00 inch Reprint After Error 0N -	1 ext Gap 0.12 inch Headup Sensor UN V
Post-Piint Action TEAR Maximum Length 10.00 inch	ITO.BAS Rest Print Action TEAP Music rest 1000
Exit Line Mode Cut Piece Gap Inten. 10 Exit Line 1	e Mode Gut Piece Gao Intern 10
Password Setup Reference 0 0 Bline Inten. 8	dSetur Reference 0 0 Bine Inter
Active Emulation Direction 0 - 0 Continuous Inten.	Direction 0 V Continuous Inten 2
Diffset 0 Threshold Detection AUTO - Active Em	Diffset 0 Threshold Detection AUTO -
Pinter Status Shit X [0	Shift× 0
Shiry J0	Shift Y 0
Get Status Clear Load Save Set Get	

- If the calibration fails to produce the correct results, you can take the following steps.
- Load the printer in the Diagnostic Tool software.
- On the left, select "Reset Printer." Once the printer has finished restarting, run the calibration again.
- If the calibration still comes back wrong, repeat the above steps, but instead of selecting "Reset Printer," choose "Factory Default."