

03 - Calibration via GSS Utility and Built-In screen

How to calibrate the GSS mobile printer with the Diagnostic Tool and built-in screen

Written By: Eric Sutter




INTRODUCTION

This guide shows you how to calibrate your GSS Mobile Printer, using the GSS Wireless Setup Utility or the built-in screen.

Download the GSS Wireless Setup Utility here.

- Go to <u>Step 1</u> to calibrate with the GSS Wireless Utility Setup desktop software.
- Go to <u>Step 3</u> to calibrate with the built-in screen of your GSS Mobile Printer.
- Go to <u>Step 6</u> to make sure the calibration went through correctly.

Step 1 — Open GSS Wireless Utility



- If this is first time setup, make sure that the printer is connected to the computer by USB.
- Download and run the GSS Wireless Setup Utility.
 - <u>https://www.emsbarcode.com/gss/wp-conten...</u>
- Check the box for the right printer.
 - *If connected by USB, it will show the three-pronged USB icon under "Interface."*
- Select the "Printer Function" option.

Step 2

	Prin	nter Function	×				Printe	r Function	×		
	Alert	Calibrate	5	Setup	Manual Na	3	Alert	Calibrate		Setup	Manual
IP Address	Model Na	Reset Printer	No	Mileage	Interface	IP Address	Calibrate	Deast Drinter	X	Mileage	Interface
10.121.80.81	MA240T		0026	0.0576	<>	10.121.80.81	MA2		~	0.0576	<>
0.121.80.77	MH240	Factory Default	90167	0.3291	<>	10.121.80.77	MH2 O GAP		Paper Height	0.3291	<··>
0.0.0	PR40	Print Test Page	0011	0.0009	*	0.0.0	PR4 OBlack Ma	rk	inch	0.0009	Ŷ
		Configuration Page					O Continuo	us	Gap		
		Ignore AUTO.BAS					O Auto Sel	ection	inch		
		Exit Line Mode						Calibrate	1		
		Password Setup						i aconora colaj			
		Wi-Fi Default						Wi-Fi Default			
	Com	Dump Text			Function	File Manager	Com	Dump Text		Printer	Function

- Select "Calibrate."
- Check the bubble for "Black Mark," and then click "Continue."
- The printer should now start calibrating. It will print a few blank labels as part of this process; go to <u>Step 6</u> to make sure the printer has calibrated correctly.

Step 3 — The Built-In screen



- At the top left is the Info button. It has a lowercase "i" on it.
- At the bottom left is the Menu button. It has an uppercase "M" on it.
- At the top right is the Power button.
 It has a power icon on it.
- At the bottom right is the Feed button. It has page with an arrow on it.
- These buttons do different things depending on what screen you're on. You can look at the little icons on the left and right edges of the screen to see what they will do.
 - On the home screen, the Power button will turn the printer off, and the Feed button will print one blank label.

Step 4 — Calibration via Built-In screen Pt.1



- On the main screen, press the Menu button to open the Main Menu.
- Press the Feed button to open the Manual Setup menu.
- Press the Menu button to scroll down until the "Sensor" option is highlighted, then press the Feed button to open that menu.

Step 5 — Calibration via Built-in screen Pt.2



- Press the Feed button to start the Auto Calibration.
- Use the Menu button to scroll down to the "Black Mark" option, then press the Feed button to confirm.
- The printer should begin calibrating now. It will print a few blank labels as part of this process. Go to <u>Step 6</u> to make sure calibration was successful.

Step 6 — Checking the Calibration

	Printer Configuration
IE	
	Printer P8-002F4C (0 0.0 0)

- If the calibration has worked correctly, you can know by checking the following:
- The edge of the labels line up with the tear-off edge (the flat metal edge just outside the printhead).
- In the GSS Wireless Utility software, a green lightbulb symbol is displayed under "Status," and is you hover over the symbol with your mouse cursor it will say "Ready."
- In the "Printer Configuration" menu (bottom left button) for the printer, the correct length and width is shown for the labels (within a few hundredths of an inch is fine).
 - (i) For my setup, I'm using 4 in. x 6 in. labels, which the software is showing.

Step 7 — If the Calibration Doesn't Work

X Press/sequent23 X	Users Alert	Printer Function X Calibrate Setup Manual Name	Lan Eng	Printer Function X
Group: All V Users Alert Group Setup Manual Name Englan V	nter Name IP Address Model	IN: Reset Printer No Mileage Interface	Users Alert	Calibrate Setup Manual Name E
Status Printer Name IP-Address Model Name Version Setable No Mileage Interface ● QSSHND-TST 10.121.88.81 Mid.249T A2.11E2D T. 24.1192/2020 0.675 ←→	-IND-TST 10.121.80.81 MA240T	0028 0.0576 ↔	Printer Name IP Address Model N	
Barcode Printer 10.121.80.77 MH240 A2.11 EZD MH219200167 0.5291 ↔	ode Printer 10.121.80.77 MH240 I92F4C 0.0.0.0 PR40	90167 0.3291 ↔ Print Test Page 0011 0.0009 ψ	SS-IND-TST 10.121.80.81 MA240T arcode Printer 10.121.80.77 MH240	Factory Default 0026 0.0576 ↔ 90167 0.3291 ↔
PS-09274C 0.0.0 PR40 2.05 WE1EZ. A4L20200011 0.0009 0		Configuration Page	3-092F4C 0.0.0.0 PR40	Print Test Page 0011 0.0009 \$
		Ignore AUTO BAS		Configuration Page
		Exit Line Mode		Ignore AUTO.BAS
		Password Setup		Exit Line Mode
Printer Configuration File Manager Command Tool RTC Setup Printer Function Bitmap Fort Manager		Wi-Fi Default		Password Setup
		Burne Text		WI-FI Default
	ation File Manager Co	p Printer Function B	nap Font M juration File Manager Com	Dump Text p Printer Function Bitmap For

- If the calibration fails to produce the correct results, you can take the following steps:
- Open the GSS Wireless Utility, and select the printer.
- Select "Printer Functions" at the bottom right.
- Select the option to "Reset Printer." Once it's done restarting, run the calibration again.
- If the calibration still comes back wrong, repeat the above steps, but instead of selecting "Reset Printer," choose "Factory Default."