





Adjusting the Sound Levels

Written By: Eric Sutter




Step 1 — Going to Settings



- Swipe up to view all your apps.
- Scroll down to find Settings, the little gear.

Step 2 — Changing Sound Settings



- Scroll down and select "Sound."
- Here you can change:
 - Media Volume: Media volume includes the volume of apps, games, music, movies, etc.
 - Alarm Volume: Alarm volume includes any alarms or reminders set up by you.
 - Notification Volume: Notification volume includes incoming texts, incoming calls, incoming alerts, etc.
- Below the volume bars you can:
 - Turn on "Do Not Disturb" which makes it so no noise will be made from the device.
 - Change the notification and alarm sounds.